

Ghosting, smudging, or not fusing properly on "Plain" paper

HP Enterprise M601, M602 and M603 Series

Issue Description:

- Printer's firmware defaults to "Light" fuser mode rather than "Normal" fuser mode.
- Poor fusing and smearing print when running normal 20-24lb printer paper (75-90gsm)
- Paper type identified as "Light" rather than "Normal" causing the fusing of the toner to weaken over long print jobs or on different quality papers.

Identify if the Paper type for "Plain" paper is set to "Normal"

How to check and change Paper Type "Plain" from "Light" to "Normal":

NOTE: This can be done at the printer's control panel or through EWS (Embedded Web Server)

Using printer's control panel:

With the printer turned on, press the following buttons:

- 1. Press the Home button on the control panel (house icon)
- 2. Press the down button until "Admin" is reached, then press "OK" button
- 3. Select "General Settings" then press "OK" button
- 4. Select "Print Quality" then press "OK" button
- 5. Select "Adjust Paper Types" then press "OK" button
- 6. Select "Plain" then press "OK" button
- 7. Select "Print Mode" then press "OK" button
- 8. Select "Normal" then press "OK" button
- 9. The settings have been updated to "Normal", **press** the Home button to return to main screen
- 10. Turn off the printer and turn the printer on again you now start printing again

Using EWS (Embedded Web Server:

- 1. Select "General tab"
- 2. "Control Panel Administration Menu"
- 3. "Administration"
- 4. "General Settings"
- 5. "Print Quality"
- 6. "Adjust Paper Types"
- 7. Click on "Go to Primary Setup Page"
- 8. Select "Plain"

- 9. Click on "Modify" at bottom of page
- 10. In the Print mode box:
 - a. If it says "Normal" no change is needed
 - b. If it says "Light Mode" select the dropdown arrow, select "Normal", then click on "Apply"

Service Technician steps:

It is not necessary to send a Service Technician out to change this setting unless needed by contract.

