

NVRAM Reset

HP Pro 200/300/400/500 Series

NVRAM Reset for M275/M276 ~ M375 ~ M401/M425/M475/M476 ~ M521/M570:



Fig. 1

With the printer off, press and hold the marked area (fig. 1)
Turn printer on and hold until **Permanent Storage initialization** is displayed
Release and printer will continue initialization.

NVRAM reset for CM1415:



Fig. 3

With the printer off, press and hold the marked area (fig. 3)
Turn printer on and hold until **Permanent Storage initialization** is displayed
Release and printer will continue initialization.