

Figure 8-9 Internal components (6 of 7)—simplex models

| Ref | Description | Part number | Qty |
|-----|--|----------------|-----|
| 1 | Link, guide ¹ | Not orderable | 1 |
| 2 | Door, rear | RC2-3604-000CN | 1 |
| 3 | Cover, rear | RL1-1822-000CN | 1 |
| 4 | Stopper, door, rear | RC2-3598-000CN | 1 |
| 5 | Cap, link | RC2-3599-000CN | 2 |
| 6 | Paper feed guide assembly (simplex and duplex products) 2 | RM1-4838-000CN | 1 |

Table 8-12 Internal components (6 of 7)

¹ Depending on which end of the link-guide attachment point has failed, replace either the rear door, or the entire product (the interior paper guide is not replaceable).

² The paper-feed guide includes the transfer roller.