Printer

Printer parts

Figure 9-1 Printer external covers and panels 10 8 *A09 *A06 *A02 *A07 (J1951) *A10 *A12 *A08 *A03 / *A06 *A05 *A01 501 13 SEE Front-door assembly SEE Right-door assembly

Table 9-1 Printer external covers and panels

| Ref | Description | Part number | Qty |
|-----|-------------------------------------|----------------|-----|
| 1 | Cover, left | RC1-9336-000CN | 1 |
| 2 | Cover, front, upper | RC1-9350-000CN | 1 |
| 3 | Cover, paper-delivery | RC1-9351-000CN | 1 |
| 4 | Duplexing-tray lower assembly | RC1-5949-000CN | 1 |
| 5 | Front internal small-cover assembly | RC1-5953-000CN | 1 |
| 6 | Right-lower cover assembly | RL1-1280-000CN | 1 |
| 7 | Cover, rear-left | RC1-9344-000CN | 1 |
| 8 | Rear-right cover assembly | RM1-4415-000CN | 1 |
| 9 | Face-down end-tray assembly | RM1-3340-000CN | 1 |
| 10 | Fixing-fan cover assembly | RM1-5950-000CN | 1 |
| 11 | Cover, rear | RL1-1210-000CN | 1 |
| 12 | Cover, face-down drive | RC1-9360-000CN | 1 |
| 13 | Switchback-cover assembly | RM1-4408-000CN | 1 |
| 14 | Filter unit, air | RC1-9313-000CN | 1 |
| 501 | Screw, tapping, truss-head, M4X10 | XB4-7401-005CN | 1 |

NOTE: Only highlighted parts are orderable.

ENWW Printer 875