


# Covers (M680)

Figure 2-6 Covers (M680)



**Table 2-12 Covers (M680)**

<b>Ref</b>	<b>Description</b>	<b>Part number</b>	<b>Qty</b>
1	Cover, right front	RC3-5551-000CN	1
2	Cover, right front, upper (M680)	RC3-5582-000CN	1
3	Cover, fan (M680)	RC3-5593-000CN	1
4	Grip, left front	RC3-5625-000CN	1
5	Grip, left rear	RC3-5626-000CN	1
6	Cover, right rear	RC3-5628-000CN	1
7	Cover, left	RC3-5629-000CN	1
8	Cover, left rear	RC3-5632-000CN	1
9	Assembly, front door	RM2-0200-000CN	1
10	Cover, rear (M680)	RM2-0205-000CN	1
11	Assembly, intermediate cover	RM2-0206-000CN	1
12	Assembly, right handle cover	RM2-0210-000CN	1
13	Bin, standard output	RM2-0214-000CN	1
14	Bezel, output bin (M680)	CZ248-67912	1
15	Assembly, switch button	RM2-0402-000CN	1
A01	Cover, inner	RM1-5520-000CN	1
A02	Screw, D, M3x8	XA9-1671-000CN	1
A04	Screw, stepped	XA9-1671-000CN	2