

Internal components (2 of 5)

Figure 2-8 Internal components (2 of 5)




Table 2-10 Internal components (2 of 5)

| Ref | Description | Part number | Qty |
|------------|--------------------------------------|--------------------|------------|
| 1 | Fan (FM1) | RK2-6270-000CN | 1 |
| 2 | Cable, flexible flat | RK2-6298-000CN | 1 |
| 3 | Fuser power supply PCA (110-127V) | RM2-6440-000CN | 1 |
| 3 | Fuser power supply PCA (220-240V) | RM2-6441-000CN | 1 |
| 4 | Driver PCA | RM2-7369-000CN | 1 |
| 5 | Low-voltage power supply (110-127V) | RM2-7913-000CN | 1 |
| 5 | Low-voltage power supply (220-240V) | RM2-7914-000CN | 1 |
| Not shown | Remote antenna (M452nw/dw) | 0960-3467 | 1 |
| Not shown | Wireless bracket (M377, M477fnw/fdw) | CF377-40007 | 1 |
| Not shown | Wireless cable (M377, M477fnw/fdw) | CF377-60115 | 1 |
| Not shown | Cable, fax (M477) | CF377-60105 | 1 |
| Not shown | Cable, FFC (M377, M477) | CF388-60116 | 1 |