



Figure 8-9 Electrical components

Table 8-11 Electrical components

Ref	Description	Part number	Qty
1	Power-supply assembly, 110-127 V (LJ 4200)	RM1-0019-050CN	1
1	Power-supply assembly, 220-240 V (LJ 4200)	RM1-0020-000CN	1
1	Power-supply assembly, 110-127 V (LJ 4250/4350)	RM1-1070-000CN	1
1	Power-supply assembly, 220-240 V (LJ 4250/4350)	RM1-1071-000CN	1
1	Power-supply assembly, 110-127 V (LJ 4300)	RM1-0107-000CN	1
1	Power-supply assembly, 220-240 V (LJ 4300)	RM1-0108-000CN	1
2	Feed assembly	RM1-0025-040CN	1
3	Cable, power-supply inlet, 110-127 V (LJ 4200/4300)	RG1-4209-000CN	1
3	Cable, power-supply inlet, 110-127 V (LJ 4250/4350)	RM1-1218-000CN	1
3	Cable, power-supply inlet, 220-240 V (LJ 4200/4300)	RG1-4230-000CN	1
3	Cable, power-supply inlet, 220-240 V (LJ 4250/4350)	RM1-1219-000CN	1
4	Connector, duplexer (LJ 4200/4300)	RG1-4222-000CN	1
4	Connector, duplexer (LJ 4250/4350)	VS1-7333-006CN	1
5	Screw, s, m3x8	XA9-1500-000CN	2
6	Cable, flat (J80-J50) (LJ 4250/4350)	RK2-0290-000CN	1
7	Cable, flat (J81-J51) (LJ 4250/4350)	RK2-0288-000CN	1
8	Screw, w/washer, m3x8	XA9-1420-000CN	7
501	Screw, w/washer, m4x6	XB2-7400-606CN	1



NOTE Flat cables for LJ 4200/4300 are wired to the power-supply assembly and are not available separately.