

Internal components (5 of 5)

Figure 4-12 Internal components (5 of 5)




Table 4-12 Internal components (5 of 5)

Ref	Description	Part number	Qty
1	Connector PCA assembly	RM1-7375-000CN	1
2	Cable, flat flexible (FFC)	RK2-3206-000CN	1
3	Connector, snap tight	VS1-7207-007CN	1
4	Cable, paper feed	RM1-7169-000CN	1
5	Cable, environmental sensor	RM1-7164-000CN	1
6	Cable, P sensor solenoid	RM1-7170-000CN	1
7	Fan (FN104)	RK2-3214-000CN	1
8	Cable, door switch	RM1-7113-000CN	1
9	Spring, tension	RU6-2475-000CN	1
11	Cable, FSR control	RM1-7156-000CN	1
12	DC controller PCA	RM1-7102-000CN	1
13	Fuser motor assembly	RM1-5051-020CN	1
14	Cable, envelope feeder	RM1-5085-000CN	1
15	Lifter assembly (1 required for each cassette)	RM1-5914-000CN	1
16	Fan (FN103)	RK2-1992-000CN	1
17	Cable, lifter motor	RM1-7162-000CN	1
18	Fan (FN102)	RK2-1989-000CN	1
19	Cable, fuser motor	RM1-7159-000CN	1
20	Sensor, assembly temperature	RM1-7420-000CN	1