

Table 2-18 Internal components (5 of 5)

Ref	Description	Part number	Qty
1	Assembly, interconnect board (ICB) PCA	RM2-5791-000CN	1
2	Cable, flat	RK2-6508-000CN	1
3	Assembly, side band cable	RM2-7474-000CN	1
4	Assembly, door sensor cable (SW106)	RM2-7476-000CN	1
5	Assembly, environmental sensor cable	RM2-7473-000CN	1
6	Cable, P sensor solenoid	RM1-7170-000CN	1
7	Fan (FN104)	RK2-6509-000CN	1
8	Assembly, door switch cable (SW101)	RM2-7478-000CN	1
9	Spring, tension	RU6-2475-000CN	1
10	Support, lifter	RC2-6441-000CN	1
11	Assembly, DC controller cable	RM2-7479-000CN	1
12	Assembly, DC controller PCA	RM2-7458-000CN	1
13	Assembly, fuser motor (M299)	RM1-5051-020CN	1
14	Cable, envelope feeder	RM1-5085-000CN	1
15	Assembly, lifter (M103)	RM1-5914-000CN	1
16	Fan (FN103)	RK2-1992-000CN	1
17	Cable, lifter motor	RM1-7162-000CN	1
18	Fan (FN102)	RK2-1989-000CN	1
19	Cable, fuser motor	RM1-7159-000CN	1
20	Assembly, temperature sensor (TH3)	RM1-7420-000CN	1
21	Assembly, DC controller cable	RM2-7481-000CN	1