

Internal components (2 of 4)

Figure 7-20 Internal components (2 of 4)




Table 7-26 Internal components (2 of 4)

Ref	Description	Part number	Qty
1	Screw, RS M3X8	XA9-1504-000CN	8
2	Arm, cam	RC2-0405-000CN	1
3	Arm, tag	RC2-0392-000CN	1
7	Screw, RS M3X6	XA9-1495-000CN	9
8	Solenoid (SL3)	RK2-0910-000CN	1
10	Holder, fan	RC2-2946-000CN	1
11	Fan	RK2-2082-000CN	1
12	Screw, TP M3X8	XA9-1648-000CN	4
13	Holder, drawer connector	RC2-0396-000CN	1
22	Solenoid (SL1)	RK2-0424-000CN	1
25	Guide, cartridge right lower	RC2-0346-000CN	1
26	Screw, RS M3X8	XA9-1561-000CN	1
27	Guide, cartridge right upper	RC1-0426-000CN	1
31	Screw, tap M3X6	XA9-1503-000CN	3
33	Motor, DC	RK2-1567-000CN	1
38	Scanner assembly (laser/scanner)	RM1-4262-000CN	1