

Internal components

Figure 2-3 Internal components (1 of 3)




Table 2-6 Internal components (1 of 3)

Ref	Description	Part number	Qty
1	Roller, transfer	RM2-5841-000	1
2	FFC, 21P	RK2-1054-000	1
3	FFC, 23P	RK2-1056-000	1
4	Solenoid, Tray 2	RK2-1096-000	1
5	FFC, 15P	RK2-4915-000	1
6	PCA, DC controller	RM2-0231-000	2
7	Cassette, Tray 2	RM2-0629-000	2
8	Assembly, paper feed	RM2-0630-000	1
9	Assembly, face-down paper delivery	RM2-0633-000	1
10	Assembly, paper pickup	RM2-0643-020	1
11	Roller, Tray 2 pickup	RM2-0644-000	1
12	Assembly, registration	RM2-0645-000	1
13	Assembly, cassette detect switch	RM2-0236-000	1
14	Pad, Tray 2 separation	RM1-2546-000	1