


Broken Transfer Belt Locks
HP CP5525, CP5225, M775MFP, M750

The locking levers that hold the ITB (Intermediate Transfer Belt) in place may break. The location of these levers is indicated in <Figure 1> below:

Figure 1: Lever Locations



Service parts have been set up to replace these broken locks. Order the appropriate part as indicated in <Figures 2 & 3> below and replace it.

NOTE: The spring on these parts is set up as a separate part from the lock itself. You may transfer the spring from the broken lock to the new service part, or order the spring in addition to the lock part.

Figure 2: Right Lock and Optional Spring



Figure 3: Left Lock and Optional Spring

